


Part of board connected to mains supply  
Partie du châssis reliée au secteur.  
Primärseite des Netzteils.  
Parte dello châssis collegata alla rete.  
Parte del chassís conectar a la red.



***http://www.schematy-tv.prv.p  
Thomson, Saba, Telefunken  
chassis: ICC 17***



▲ Sicherheitsbauteil  
Bei Ersatz nur Originalteil verwenden  
▲ Safety Part  
When replacing, use original part only  
▲ Pièce de sécurité  
Utilisez que les pièces d'origine


Standard	picture carrier [MHz]	sound carrier [MHz]	SWO1	SWO2
B/G	38.90		0	1
I	38.90	32.90/32.35	0	0
D/K	38.90	32.40/32.65	0	1
K'	38.90	32.40/33.05	0	0
L	38.90	32.40/33.05	0	0
L'	33.90	40.40	1	0
AV	X	X	X	X

chassis ICC17

T = 20ms




T = 64µs



http://www.servistv.republika.pl  
-Wrocław, tel. 362-14-29-

(DP) SAFETY

http://www.schematy-tv.prv.pl



(MAIN)  
(OS)

\* = see CT 17xxx partslist

